

CAN-bus

Make	Model series	Model
Alfa	147	2000-
Audi	A3	2003-
Audi	A4	2000-
Audi	A4	2005-
Audi	A6	2005-
BMW	1-series [E87]	2003-
BMW	3-series [E90] [2005 -]	2005-
BMW	5-series [E60] [2003 -]	2003-
Citroën	C2	2003-
Citroën	C3 I [2002 - 2005]	2002-
2004-	C4	2004-
Citroën	C4 Picasso [2006 -]	2006-
Citroën	C5 [2001 - 2004]	2001-
Citroën	C5 [2004 -]	2004-
Fiat	Grande Punto	2005-
Fiat	Panda [2003 -]	2003-
Fiat	Stilo	2001-
Ford	C-Max [2007 -]	2007-
Ford	Focus [2005 -]	2005-
Mercedes	A-Class [168]	1998-
Mercedes	C-Class [203]	2001-
Mercedes	E-Class [210]	1995-
Opel	Astra H [2004 -]	2004-
Opel	Corsa C [2001 -]	2001-
Opel	Meriva	2003-
Opel	Vectra C [2002 -]	2002-
Peugeot	206	1998-
Peugeot	307	2001-
Peugeot	406	2000-
Peugeot	407	2004-
Seat	Altea	2004-
Seat	Ibiza	2002-
Seat	Leon [2005 -]	2005-
Seat	Toledo [2004 -]	2004-
Skoda	Octavia [2004 -]	2004-
Smart	Smart Fortwo	1998-

CAN-bus

Make	Model series	Model
Volvo	40 Serie [1996 - 2004]	1996-
Volkswagen	Caddy [2004 -]	2004-
Volkswagen	Golf V [2004 -]	2004-
Volkswagen	Golf V Plus	2005-
Volkswagen	Jetta [2005 -]	2005-
Volkswagen	Passat V [2005 -]	2005-
Volkswagen	Polo IV [2002 - 2005]	2002-
Volkswagen	Polo IV [2005 -]	2005-
Volkswagen	Touran	2003-